

SewLong Tower Clamp Shade Sail Nautique G

#1

INSIDE

FWD

Bolts:
1/4-20 x 1" SHB

Install Clamp on the AFT Bar of the tower. Place it with about a 1.25" gap between the top clamp and the corss plate of the tower. Snug the bolts to hold them in place but leave them slightly loose for future adjustment.

#2

FWD
OUTSIDE

Bolts:
1/4-20 x 1/2" SFHB

Install shade sail receiver. The recommended pitch will be the 3rd hole from the top on the back side and the 3rd hole from the bottom on the front to pitch the sail up. Repeat on other side.

#3

Place poles in receiver and adjust width. You can addust pitch of sail per your needs. The width is what must be correct to keep canvas stretched in to place.

#4

96 +/-

8' Poles

92 +/-

5' Poles

Once width and height are in the desired location, tighten all bolts. The clamp on the tower must be very secure to prevent twisting and loosening of the sail.